

# Airless Spray Machine

## AgSafe Safe Work Procedure

1. Eye protection must be worn while operating an airless; the minimum standard being C.S.A. approved safety goggles.
2. Prior to plugging in the machine check the cord to ensure that there is no damage that could cause an electrical shock.
3. Prior to starting the machine check and ensure that all fittings are tight to safe guard against the pressure blowing them apart.
4. While operating the machine, keep a watch on the hose to make sure that it does not tangle causing an excessive buildup of pressure.
5. When you are finished with the machine make sure that it is unplugged and the pressure in the hose released.

Please use the following ***Safe Work Procedures*** as a guideline to building your own safe work procedures.