

# Round Baler

## AgSafe Safe Work Procedure

1. Do not allow anyone to stand near the rear of the baler when a bale is ejected
2. Never eject bales on a slope where they could roll
3. Engage the mechanical gate safety lock before entering the open rear gate area. Do not rely on a “hydraulic lock”
4. The large springs and hoses store significant amounts of energy. Relieve the tension and pressure prior to servicing
5. Maintain proper belt tension (excessive tension may cause fire)

Please use the following **Safe Work Procedures** as a guideline to building your own safe work procedures.